

# RSLogix Micro Project Report



Processor Information

---

Processor Type: Bul.1763      MicroLogix 1100 Series B

Processor Name: TREATER

Total Memory Used: 216 Instruction Words Used - 79 Data Table Words Used

Total Memory Left: 6440 Instruction Words Left

Program Files: 6

Data Files: 10

Program ID: d125

I/O Configuration

---

0 Bul.1763  
1  
2  
3  
4

MicroLogix 1100 Series B

## Channel Configuration

## CHANNEL 0 (SYSTEM) - Driver: Modbus RTU Master

CHANNEL 0 (SYSTEM) - Driver: Modbus RTU Master Edit Resource/Owner Timeout: 60  
CHANNEL 0 (SYSTEM) - Driver: Modbus RTU Master Passthru Link ID: 1  
CHANNEL 0 (SYSTEM) - Driver: Modbus RTU Master Write Protected: No  
CHANNEL 0 (SYSTEM) - Driver: Modbus RTU Master Comms Servicing Selection: Yes  
CHANNEL 0 (SYSTEM) - Driver: Modbus RTU Master Message Servicing Selection: Yes  
CHANNEL 0 (SYSTEM) - Driver: Modbus RTU Master 1st AWA Append Character: \d  
CHANNEL 0 (SYSTEM) - Driver: Modbus RTU Master 2nd AWA Append Character: \a

Baud: 19200

Parity: NONE

Control Line : No Handshaking

InterCharacter Timeout(x1 ms): 0

Pre Transmit Delay(x1 ms): 0

## CHANNEL 1 (SYSTEM) - Driver: Ethernet

CHANNEL 1 (SYSTEM) - Driver: Ethernet Edit Resource/Owner Timeout: 60  
CHANNEL 1 (SYSTEM) - Driver: Ethernet Passthru Link ID: 1  
CHANNEL 1 (SYSTEM) - Driver: Ethernet Write Protected: No  
CHANNEL 1 (SYSTEM) - Driver: Ethernet Comms Servicing Selection: Yes  
CHANNEL 1 (SYSTEM) - Driver: Ethernet Message Servicing Selection: Yes

Hardware Address: 00:00:00:00:00:00

IP Address: 0.0.0.0

Subnet Mask: 0.0.0.0

Gateway Address: 0.0.0.0

Msg Connection Timeout (x 1mS): 15000

Msg Reply Timeout (x mS): 3000

Inactivity Timeout (x Min): 30

Bootp Enable: Yes

Dhcp Enable No

SNMP Enable: No

HTTP Enable: Yes

Auto Negotiate Enable: Yes

Port Speed Enable: 10/100 Mbps Full Duplex/Half Duplex

Contact:


Location:

Program File List


| Name     | Number | Type   | Rungs | Debug | Bytes |
|----------|--------|--------|-------|-------|-------|
| [SYSTEM] | 0      | SYS    | 0     | No    | 0     |
|          | 1      | SYS    | 0     | No    | 0     |
| MAIN     | 2      | LADDER | 4     | No    | 30    |
| IO       | 3      | LADDER | 7     | No    | 99    |
| POSITION | 4      | LADDER | 10    | No    | 271   |
| CONTROL  | 5      | LADDER | 10    | No    | 251   |


Data File List


| Name    | Number | Type | Scope  | Debug | Words | Elements | Last  |
|---------|--------|------|--------|-------|-------|----------|-------|
| OUTPUT  | 0      | O    | Global | No    | 12    | 4        | O:3   |
| INPUT   | 1      | I    | Global | No    | 18    | 6        | I:5   |
| STATUS  | 2      | S    | Global | No    | 0     | 66       | S:65  |
| BINARY  | 3      | B    | Global | No    | 2     | 2        | B3:1  |
| TIMER   | 4      | T    | Global | No    | 12    | 4        | T4:3  |
| COUNTER | 5      | C    | Global | No    | 3     | 1        | C5:0  |
| CONTROL | 6      | R    | Global | No    | 3     | 1        | R6:0  |
| INTEGER | 7      | N    | Global | No    | 2     | 2        | N7:1  |
| FLOAT   | 8      | F    | Global | No    | 2     | 1        | F8:0  |
| MESSAGE | 9      | MG   | Global | No    | 25    | 1        | MG9:0 |














| Offset | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |          |            |      |          |
|--------|----|----|----|----|----|----|---|---|---|---|---|---|---|---|---|---|----------|------------|------|----------|
| O:0.0  | 0  | 0  | 0  | 0  | 0  | 0  | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | Bul.1763 | MicroLogix | 1100 | Series B |
| O:0.1  | 0  | 0  | 0  | 0  | 0  | 0  | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | Bul.1763 | MicroLogix | 1100 | Series B |
| O:0.2  | 0  | 0  | 0  | 0  | 0  | 0  | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | Bul.1763 | MicroLogix | 1100 | Series B |
| O:0.3  | 0  | 0  | 0  | 0  | 0  | 0  | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | Bul.1763 | MicroLogix | 1100 | Series B |



**Main**

Processor Mode S:1/0 - S:1/4 = Remote Run  
On Power up Go To Run (Mode Behavior) S:1/12 = 0  
First Pass S:1/15 = No  
Free Running Clock S:4 = 1101-0101-1000-0011

**Proc**

OS Catalog Number S:57 = 1100                      User Program Type S:63 = 8001h  
OS Series S:58 = B                                  Compiler Revision Number S:64 =  
OS FRS S:59 =  
Processor Catalog Number S:60 =  
Processor Series S:61 = A  
Processor FRN S:62 =

**Scan Times**

Maximum (x10 ms) S:22 = 81  
Watchdog (x10 ms) S:3 (high byte) = 10  
Last 100 uSec Scan Time S:35 = 0  
Scan Toggle Bit S:33/9 = 0

**Math**

Math Overflow Selected S:2/14 = 0                      Math Register (lo word) S:13 = 0  
Overflow Trap S:5/0 = 0                              Math Register (high word) S:14-S:13 = 0  
Carry S:0/0 = 0                                      Math Register (32 Bit) S:14-S:13 = 0  
Overflow S:0/1 = 0  
Zero Bit S:0/2 = 1  
Sign Bit S:0/3 = 0

**Chan 0**

Processor Mode S:1/0- S:1/4 = Remote Run  
Node Address S:15 (low byte) = 0                      Outgoing Msg Cmd Pending S:33/2 = 0  
Baud Rate S:15 (high byte) = ?  
Channel Mode S:33/3 = 0  
Comms Active S:33/4 = 0  
Incoming Cmd Pending S:33/0 = 0  
Msg Reply Pending S:33/1 = 0

**Debug**

Suspend Code S:7 = 0  
Suspend File S:8 = 0

**Errors**

Fault Override At Power Up S:1/8 = 0                      Fault Routine S:29 = 0  
Startup Protection Fault S:1/9 = 0                      Major Error S:6 = 0h  
Major Error Halt S:1/13 = 0  
Overflow Trap S:5/0 = 0                              Error Description:  
Control Register Error S:5/2 = 0  
Major Error Executing User Fault Rtn. S:5/3 = 0  
Battery Low S:5/11 = 0  
Input Filter Selection Modified S:5/13 = 0  
ASCII String Manipulation error S:5/15 = 0

**Protection**

Deny Future Access S:1/14 = No  
Data File Overwrite Protection Lost S:36/10 = False

**Mem Module**

Memory Module Loaded On Boot S:5/8 = 0  
Password Mismatch S:5/9 = 0  
Load Memory Module On Memory Error S:1/10 = 0  
Load Memory Module Always S:1/11 = 0  
On Power up Go To Run (Mode Behavior) S:1/12 = 0  
Program Compare S:2/9 = 0  
Data File Overwrite Protection Lost S:36/10 = 0

**Forces**

Forces Enabled S:1/5 = Yes  
Forces Installed S:1/6 = No

| Offset | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | (Symbol) | Description |
|--------|----|----|----|----|----|----|---|---|---|---|---|---|---|---|---|---|----------|-------------|
| B3:0   | 0  | 1  | 0  | 1  | 0  | 0  | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 |          |             |
| B3:1   | 0  | 0  | 0  | 0  | 0  | 0  | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 |          |             |

| Offset | EN | TT | DN | BASE    | PRE | ACC | (Symbol) | Description |
|--------|----|----|----|---------|-----|-----|----------|-------------|
| T4:0   | 0  | 0  | 0  | 1.0 sec | 10  | 0   | FILL     | TIMER       |
| T4:1   | 0  | 0  | 0  | 1.0 sec | 20  | 0   | DRAIN    | TIMER       |
| T4:2   | 0  | 0  | 0  | 1.0 sec | 10  | 0   | FLUSH    | TIMER       |
| T4:3   | 0  | 0  | 0  | .01 sec | 0   | 0   |          |             |

| Offset | CU | CD | DN | OV | UN | UA | PRE | ACC | (Symbol) | Description |
|--------|----|----|----|----|----|----|-----|-----|----------|-------------|
| C5:0   | 0  | 0  | 0  | 0  | 0  | 0  | 0   | 0   |          |             |

| Offset | EN | EU | DN | EM | ER | UL | IN | FD | LEN | POS | (Symbol) | Description |
|--------|----|----|----|----|----|----|----|----|-----|-----|----------|-------------|
| R6:0   | 0  | 0  | 0  | 0  | 0  | 0  | 0  | 0  | 0   | 0   |          |             |

Data File N7 (dec) -- INTEGER

|        |   |   |   |   |   |   |   |   |   |   |
|--------|---|---|---|---|---|---|---|---|---|---|
| Offset | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
| N7:0   | 0 | 0 |   |   |   |   |   |   |   |   |

Data File F8 -- FLOAT

|        |   |   |   |   |   |
|--------|---|---|---|---|---|
| Offset | 0 | 1 | 2 | 3 | 4 |
| F8:0   | 0 |   |   |   |   |

| Offset | IA | RBL | LBN | RBN | CHN | NOD | MTO | NB | TFT | TFN | ELE | SEL | BK | UC | TO | CO |  |
|--------|----|-----|-----|-----|-----|-----|-----|----|-----|-----|-----|-----|----|----|----|----|--|
| MG9:0  | 0  | 0   | 0   | 0   | 0   | 0   | 0   | 0  | 0   | 0   | 0   | 0   | 0  | 0  | 0  | 0  |  |

## Address/Symbol Database

| Address | Symbol | Scope  | Description                                                      | Sym Group | Dev. Code |
|---------|--------|--------|------------------------------------------------------------------|-----------|-----------|
|         | U2     | Global |                                                                  |           |           |
|         | F      | Global | FF F F F FF                                                      |           |           |
|         | FF     | Global | F F F FF F                                                       |           |           |
| B3:0/0  |        |        | CYCLE RESET/INTERRUPT                                            |           |           |
| B3:0/1  |        |        | FILL                                                             |           |           |
| B3:0/2  |        |        | DRAIN                                                            |           |           |
| B3:0/3  |        |        | FLUSH                                                            |           |           |
| B3:0/4  |        |        | CALL                                                             |           |           |
| B3:0/5  |        |        | HOME                                                             |           |           |
| B3:0/6  |        |        | SERVO                                                            |           |           |
| B3:0/7  |        |        |                                                                  |           |           |
| B3:0/8  |        |        | CYCLE TRIGGER                                                    |           |           |
| B3:0/9  |        |        | ONS                                                              |           |           |
| B3:0/10 |        |        | CYCLE INTERRUPT                                                  |           |           |
| B3:0/11 |        |        | ONS                                                              |           |           |
| B3:0/12 |        |        |                                                                  |           |           |
| B3:0/13 |        |        | CYCLE RESET                                                      |           |           |
| B3:0/14 |        |        | ONS                                                              |           |           |
| B3:0/15 |        |        | CYCLE RUNNING                                                    |           |           |
| B3:1/0  |        |        | ONS                                                              |           |           |
| B3:1/1  |        |        | ONS                                                              |           |           |
| B3:1/2  |        |        | ONS                                                              |           |           |
| B3:1/3  |        |        | SERVO TRIGGER                                                    |           |           |
| B3:1/4  |        |        | SERVO INTERRUPT                                                  |           |           |
| B3:1/5  |        |        | ONS                                                              |           |           |
| I:0/0   |        |        | HOME INP                                                         |           |           |
| I:0/1   |        |        | FILL INP                                                         |           |           |
| I:0/2   |        |        | DRAIN INP                                                        |           |           |
| I:0/3   |        |        | FLUSH INP                                                        |           |           |
| I:0/4   |        |        | CYCLE CALL INP                                                   |           |           |
| N7:0    |        |        | VALVE POSITION 0= HOME 1= FILL 2= DRAIN 3 = FLUSH 4 = TRAVELLING |           |           |
| N7:1    |        |        | DESIRED 0= HOME 1=FILL 2=DRAIN 3=FLUSH                           |           |           |
| O:0/0   |        |        | SERVO OUT                                                        |           |           |
| S:0     |        |        | Arithmetic Flags                                                 |           |           |
| S:0/0   |        |        | Processor Arithmetic Carry Flag                                  |           |           |
| S:0/1   |        |        | Processor Arithmetic Underflow/ Overflow Flag                    |           |           |
| S:0/2   |        |        | Processor Arithmetic Zero Flag                                   |           |           |
| S:0/3   |        |        | Processor Arithmetic Sign Flag                                   |           |           |
| S:1     |        |        | Processor Mode Status/ Control                                   |           |           |
| S:1/0   |        |        | Processor Mode Bit 0                                             |           |           |
| S:1/1   |        |        | Processor Mode Bit 1                                             |           |           |
| S:1/2   |        |        | Processor Mode Bit 2                                             |           |           |
| S:1/3   |        |        | Processor Mode Bit 3                                             |           |           |
| S:1/4   |        |        | Processor Mode Bit 4                                             |           |           |
| S:1/5   |        |        | Forces Enabled                                                   |           |           |
| S:1/6   |        |        | Forces Present                                                   |           |           |
| S:1/7   |        |        | Comms Active                                                     |           |           |
| S:1/8   |        |        | Fault Override at Powerup                                        |           |           |
| S:1/9   |        |        | Startup Protection Fault                                         |           |           |
| S:1/10  |        |        | Load Memory Module on Memory Error                               |           |           |
| S:1/11  |        |        | Load Memory Module Always                                        |           |           |
| S:1/12  |        |        | Load Memory Module and RUN                                       |           |           |
| S:1/13  |        |        | Major Error Halted                                               |           |           |
| S:1/14  |        |        | Access Denied                                                    |           |           |
| S:1/15  |        |        | First Pass                                                       |           |           |
| S:2/0   |        |        | STI Pending                                                      |           |           |
| S:2/1   |        |        | STI Enabled                                                      |           |           |
| S:2/2   |        |        | STI Executing                                                    |           |           |
| S:2/3   |        |        | Index Addressing File Range                                      |           |           |
| S:2/4   |        |        | Saved with Debug Single Step                                     |           |           |
| S:2/5   |        |        | DH-485 Incoming Command Pending                                  |           |           |
| S:2/6   |        |        | DH-485 Message Reply Pending                                     |           |           |
| S:2/7   |        |        | DH-485 Outgoing Message Command Pending                          |           |           |
| S:2/15  |        |        | Comms Servicing Selection                                        |           |           |
| S:3     |        |        | Current Scan Time/ Watchdog Scan Time                            |           |           |
| S:4     |        |        | Time Base                                                        |           |           |
| S:5/0   |        |        | Overflow Trap                                                    |           |           |
| S:5/2   |        |        | Control Register Error                                           |           |           |
| S:5/3   |        |        | Major Err Detected Executing UserFault Routine                   |           |           |
| S:5/4   |        |        | M0-M1 Referenced on Disabled Slot                                |           |           |
| S:5/8   |        |        | Memory Module Boot                                               |           |           |
| S:5/9   |        |        | Memory Module Password Mismatch                                  |           |           |
| S:5/10  |        |        | STI Overflow                                                     |           |           |
| S:5/11  |        |        | Battery Low                                                      |           |           |
| S:6     |        |        | Major Error Fault Code                                           |           |           |
| S:7     |        |        | Suspend Code                                                     |           |           |
| S:8     |        |        | Suspend File                                                     |           |           |
| S:9     |        |        | Active Nodes                                                     |           |           |
| S:10    |        |        | Active Nodes                                                     |           |           |
| S:11    |        |        | I/O Slot Enables                                                 |           |           |
| S:12    |        |        | I/O Slot Enables                                                 |           |           |
| S:13    |        |        | Math Register                                                    |           |           |
| S:14    |        |        | Math Register                                                    |           |           |
| S:15    |        |        | Node Address/ Baud Rate                                          |           |           |

## Address/Symbol Database

| Address | Symbol | Scope | Description                                  | Sym Group | Dev. Code |
|---------|--------|-------|----------------------------------------------|-----------|-----------|
| S:16    |        |       | Debug Single Step Rung                       |           |           |
| S:17    |        |       | Debug Single Step File                       |           |           |
| S:18    |        |       | Debug Single Step Breakpoint Rung            |           |           |
| S:19    |        |       | Debug Single Step Breakpoint File            |           |           |
| S:20    |        |       | Debug Fault/ Powerdown Rung                  |           |           |
| S:21    |        |       | Debug Fault/ Powerdown File                  |           |           |
| S:22    |        |       | Maximum Observed Scan Time                   |           |           |
| S:23    |        |       | Average Scan Time                            |           |           |
| S:24    |        |       | Index Register                               |           |           |
| S:25    |        |       | I/O Interrupt Pending                        |           |           |
| S:26    |        |       | I/O Interrupt Pending                        |           |           |
| S:27    |        |       | I/O Interrupt Enabled                        |           |           |
| S:28    |        |       | I/O Interrupt Enabled                        |           |           |
| S:29    |        |       | User Fault Routine File Number               |           |           |
| S:30    |        |       | STI Setpoint                                 |           |           |
| S:31    |        |       | STI File Number                              |           |           |
| S:32    |        |       | I/O Interrupt Executing                      |           |           |
| S:33    |        |       | Extended Proc Status Control Word            |           |           |
| S:33/0  |        |       | Incoming Command Pending                     |           |           |
| S:33/1  |        |       | Message Reply Pending                        |           |           |
| S:33/2  |        |       | Outgoing Message Command Pending             |           |           |
| S:33/3  |        |       | Selection Status User/DF1                    |           |           |
| S:33/4  |        |       | Communicat Active                            |           |           |
| S:33/5  |        |       | Communicat Servicing Selection               |           |           |
| S:33/6  |        |       | Message Servicing Selection Channel 0        |           |           |
| S:33/7  |        |       | Message Servicing Selection Channel 1        |           |           |
| S:33/8  |        |       | Interrupt Latency Control Flag               |           |           |
| S:33/9  |        |       | Scan Toggle Flag                             |           |           |
| S:33/10 |        |       | Discrete Input Interrupt Reconfigur Flag     |           |           |
| S:33/11 |        |       | Online Edit Status                           |           |           |
| S:33/12 |        |       | Online Edit Status                           |           |           |
| S:33/13 |        |       | Scan Time Timebase Selection                 |           |           |
| S:33/14 |        |       | DTR Control Bit                              |           |           |
| S:33/15 |        |       | DTR Force Bit                                |           |           |
| S:34    |        |       | Pass-thru Disabled                           |           |           |
| S:34/0  |        |       | Pass-Thru Disabled Flag                      |           |           |
| S:34/1  |        |       | DH+ Active Node Table Enable Flag            |           |           |
| S:34/2  |        |       | Floating Point Math Flag Disable,Fl          |           |           |
| S:35    |        |       | Last 1 ms Scan Time                          |           |           |
| S:36    |        |       | Extended Minor Error Bits                    |           |           |
| S:36/8  |        |       | DII Lost                                     |           |           |
| S:36/9  |        |       | STI Lost                                     |           |           |
| S:36/10 |        |       | Memory Module Data File Overwrite Protection |           |           |
| S:37    |        |       | Clock Calendar Year                          |           |           |
| S:38    |        |       | Clock Calendar Month                         |           |           |
| S:39    |        |       | Clock Calendar Day                           |           |           |
| S:40    |        |       | Clock Calendar Hours                         |           |           |
| S:41    |        |       | Clock Calendar Minutes                       |           |           |
| S:42    |        |       | Clock Calendar Seconds                       |           |           |
| S:43    |        |       | STI Interrupt Time                           |           |           |
| S:44    |        |       | I/O Event Interrupt Time                     |           |           |
| S:45    |        |       | DII Interrupt Time                           |           |           |
| S:46    |        |       | Discrete Input Interrupt- File Number        |           |           |
| S:47    |        |       | Discrete Input Interrupt- Slot Number        |           |           |
| S:48    |        |       | Discrete Input Interrupt- Bit Mask           |           |           |
| S:49    |        |       | Discrete Input Interrupt- Compare Value      |           |           |
| S:50    |        |       | Processor Catalog Number                     |           |           |
| S:51    |        |       | Discrete Input Interrupt- Return Number      |           |           |
| S:52    |        |       | Discrete Input Interrupt- Accumulat          |           |           |
| S:53    |        |       | Reserved/ Clock Calendar Day of the Week     |           |           |
| S:55    |        |       | Last DII Scan Time                           |           |           |
| S:56    |        |       | Maximum Observed DII Scan Time               |           |           |
| S:57    |        |       | Operating System Catalog Number              |           |           |
| S:58    |        |       | Operating System Series                      |           |           |
| S:59    |        |       | Operating System FRN                         |           |           |
| S:61    |        |       | Processor Series                             |           |           |
| S:62    |        |       | Processor Revision                           |           |           |
| S:63    |        |       | User Program Type                            |           |           |
| S:64    |        |       | User Program Functional Index                |           |           |
| S:65    |        |       | User RAM Size                                |           |           |
| S:66    |        |       | Flash EEPROM Size                            |           |           |
| S:67    |        |       | Channel 0 Active Nodes                       |           |           |
| S:68    |        |       | Channel 0 Active Nodes                       |           |           |
| S:69    |        |       | Channel 0 Active Nodes                       |           |           |
| S:70    |        |       | Channel 0 Active Nodes                       |           |           |
| S:71    |        |       | Channel 0 Active Nodes                       |           |           |
| S:72    |        |       | Channel 0 Active Nodes                       |           |           |
| S:73    |        |       | Channel 0 Active Nodes                       |           |           |
| S:74    |        |       | Channel 0 Active Nodes                       |           |           |
| S:75    |        |       | Channel 0 Active Nodes                       |           |           |
| S:76    |        |       | Channel 0 Active Nodes                       |           |           |
| S:77    |        |       | Channel 0 Active Nodes                       |           |           |
| S:78    |        |       | Channel 0 Active Nodes                       |           |           |
| S:79    |        |       | Channel 0 Active Nodes                       |           |           |

Address/Symbol Database

| Address | Symbol | Scope | Description            | Sym Group | Dev. Code |
|---------|--------|-------|------------------------|-----------|-----------|
| S:80    |        |       | Channel 0 Active Nodes |           |           |
| S:81    |        |       | Channel 0 Active Nodes |           |           |
| S:82    |        |       | Channel 0 Active Nodes |           |           |
| S:83    |        |       | DH+ Active Nodes       |           |           |
| S:84    |        |       | DH+ Active Nodes       |           |           |
| S:85    |        |       | DH+ Active Nodes       |           |           |
| S:86    |        |       | DH+ Active Nodes       |           |           |
| T4:0    |        |       | FILL TIMER             |           |           |
| T4:1    |        |       | DRAIN TIMER            |           |           |
| T4:2    |        |       | FLUSH TIMER            |           |           |
| U:3     |        |       | IO                     |           |           |
| U:4     |        |       | POSITION               |           |           |
| U:5     |        |       | CONTROL                |           |           |

| Address | Instruction | Description |
|---------|-------------|-------------|
|---------|-------------|-------------|

Symbol Group Database

| Group_Name | Description |
|------------|-------------|
|------------|-------------|